



Notes:

- All labeled ground nodes connect independently to the main star point.
- For KT88 tubes, each bias test point should read 0.0625 volts after full warm up assuming 480 volts B+.
- For KT90 tubes, each bias test point should read 0.073 volts after full warm up, assuming 480 volts B+.
- Phase compensator is adjusted until amplitude readings off phase inverter are equal in height.

Title: Dynaco MKIII Rev. 2 Power Supply

Size	Number	Rev
11x17	1	1
Date: 6/4/2013	Drawn by: Ben S.	
Filename: Rev. 2	Sheet: 2	