

## Parts List

### **Resistors:**

(all resistors are ½ watt, unless otherwise noted)

**R101, 201:** 47K, metal film (47.5K is OK here)

**R102, 202, 108, 208:** 220 ohms, Carbon Film (or non-inductive film resistor type)

**R103, 203:** 820 ohms

**R104, 110, 204, 210:** 100K

**R105, 205:** 470K Metal Film (475K is OK here)

**R106, 206:** 22K Metal Film (22.1K is OK here)

**R107, 207:** 680K Metal Film (681K is OK here)

**R109, 209:** 1.8K

**R111, 211:** 100K, 2 watts

**R112, 212:** 470 ohms, Carbon Film (or non-inductive film resistor type)

**R301:** 8.2K

**R302:** 22K

### **Capacitors:**

**C101, 201, 102, 202:** 47uF, 6.3V, audio type (Silmic-II, Muse, etc.)

**C103, 203:** 100n (0.1uF), 400V polypropylene

**C104, 204:** 3n3 (0.0033uF), Film or Mica

**C105, 205:** 10n (0.01uF), Film or Mica

**C106, 206:** (*mislabeled C112, 212 on first gen boards*) 470n (0.47uF), 400V polypropylene

**C301, 302:** 22uF, 350V low-ESR electrolytic (Nichicon UCS, Panasonic EE, United KXG, etc.)