


One of ground point for speaker ground connection.

Dynaco MK3 Cap Board connection diagram. All connection points were basic on the original MK3 driver board.



This is the main ground connected to chassis by screw/standoff

- to MK3 driver board point #2
- from transformer bias tap (55v-60v) AC
- to MK3 driver board point #6
- to MK3 driver board point #5
- to output transformer primary centre tap (B+)
- C-354 Choke 2 connection points
- from tube GZ34 pin #8
- from 6.3v centre tap
- main ground connection